

MINIMUM SPECIFICATIONS FOR INFINITY 60 AIR COMPRESSOR

- 60 CFM @ 150 PSI
- 13 GPM @ 2470 PSI (ACTUAL 13.3 GPM W/1.58 CIR)
- MINIMUM RESERVOIR SIZE 25 GALLONS
- INFINITY SYSTEM IS TO RUN CONTINUOUSLY AND WILL UNLOAD THE COMPRESSOR AIR SUMP PRESSURE.
- WHEN INFINITY IS INSTALLED WITH OTHER HYDRAULIC DRIVE EQUIPMENT IT WILL REQUIRE A DEDICATED FLOW LINE.
- IF OTHER HYDRAULICS ARE REQUIRED THE RESERVOIR SIZE SHOULD BE 25 GAL PLUS THE OTHER MANUFACTURERS REQUIREMENTS.
- A DOWN STREAM ½" AUTO DRAIN MOISTURE TRAP IS REQUIRED TO CATCH MOISTURE AFTER THE AFTERCOOLER.
- A MINIMUM ¾" 3000 PSI HIGH PRESSURE FEED HOSE TO THE VALVE BLOCK IS REQUIRED.
- A MINIMUM ¾" 1000 PSI MEDIUM PRESSURE RETURN HOSE TO THE HYDRAULIC SYSTEM IS REQUIRED.
- A MINIMUM 200 PSI ¾" AIR FEED DOWN STREAM OF INFINITY AIR OUTLET IS REQUIRED.
- 12 VDC ELECTRICAL REQUIREMENTS:
 - SUPPLY BATTERY +12 VDC
 - SUPPLY BATTERY GROUND
 - SUPPLY BATTERY +12 VDC SWITCHED
 - 12 VDC OUTPUT DURING COMPRESSOR OPERATION
- MOUNTING SURFACE MUST BE CAPABLE OF 300 LB LOAD SPREAD OVER THE SIX MOUNTING HOLES. OVERALL PACKAGE DIMENSIONS 20.25" WIDE X 19.5" HIGH X 36.75" LONG. ALLOW ROOM FOR AIR AND HYDRAULIC CONNECTIONS.
- COOLING AIR INTAKE MUST NOT SEE AIR TEMPERATURES ABOVE AMBIENT.
- COOLING AIR DISCHARGE MUST HAVE 10" CLEARANCE FROM ANY OBSTRUCTIONS.
- AMBIENT RUNNING CONDITIONS: -20° TO 120° FARENHEIT.
- 10° MAXIMUM OPERATING SLOPE.